ERSATZTEILLISTE OL 810ex

M-OSD-10017-12

6. Ersatzteilliste

6.1 Lower base unit

6.1.1 Zeichnung



6.1.2 Liste

NR.	BEZEICHNUNG	BESTELL-NR.	BEMERKUNG
1	HOPPING ROLLER SHAFT ASSY	3PA4083-6019G1	
2	BEARING	4PP4083-6022P2	
3	ONE-WAY CLUTCH GEAR	4PB4083-6024P1	
4	RESIST ROLLER	3PB4083-6030P1	
5	BEARING (RESIST)	4PP4083-6031P1	
6	TRANSFER ROLLER	3YB4083-7640P1	
7	TR GEAR	3PP4083-6290P1	
8	BACK-UP ROLLER	3PB4083-6064P2	
9	BIAS SPRING	4PP4083-7620P1	
10	BUSH	4PP4083-6052P1	
11	RESET LEVER L	3PP4083-6053P1	
12	RESET LEVER R	3PP4083-6054P1	
13	SWITCH ARM	4PP4083-6058P1	
14	RESET SPRING	4PP4083-6057P1	
15	IDLE GEAR	4PP4083-6080P1	
16	IDLE GEAR	4PP4083-6081P1	
17	SENSOR PLATE (INLET)	4PP4083-6083P1	
18	SENSOR PLATE (OUTLET)	4PA4083-6025G1	
19	TONER SENSOR (ADHESION)	4PP4083-6086G1	
20	DISELECTRIFICATION BAR	4PB4083-3182P3	
21	FUSING UNIT ASSY, 120V	2YX4083-6100G5	120V
	FUSING UNIT ASSY, 230V	2YX4083-6100G6	230V
22	FUSER LAMP (HEIZLAMPE)	3PB4083-6103P2	
23	EJECT ROLLER ASSY	2PA4083-7680G1	
24	MANUAL FEED GUIDE ASSY	2PA4128-1149G1	
25	FACE DOWN STACKER COVER ASSY	2PA4128-1134G1	
25A	STACKER COVER HOLDER KNOB	3PP4128-1140P2	R+L
26	LED HEAD ASSY	4YA4116-1224G1	
27	DUMPER ARM (CAULKING)	4PP4083-6191G1	
28	LOWER BASE	2PP4083-6801G2	
29	STACKER COVER DUMPER	4PB4083-6197P1	
31	PULSE MOTOR (MAIN/DRUM)	4PB4083-7615P1	
32	PULSE MOTRO (REGISTRATION)	4PB4083-7616P1	
33	PULSE MOTOR (M/D) IDLE GEAR	3PP4083-7618P1	
34	PULSE MOTOR (R) IDLE GEAR	3PP4083-7619P1	
35	LED HEAD CABLE ASSY	4YX4083-7668G1	
36	IMAGE DRUM CARTRIDGE	OPTION	

NR.	BEZEICHNUNG	BESTELL-NR.	BEMERKUNG
37	TONER CARTRIDGE	OPTION	
38	REDUCTION GEAR	3PP4083-7617P1	
39	FG PLATE (O.P.)	4PP4083-7663P1	
40	HOPPING ROLLER RUBBER	4PB4122-1280P1	
41	BEARING (TR)	3PP4083-6289P1	
42	LED CONTACT	4PP4083-7664P1	

6.2 Upper cover unit

6.2.1 Zeichnung



6.2.2 Liste

NR.	BEZEICHNUNG	BESTELL-NR.	BEMERKUNG
1	UPPER COVER	1PP4128-1133P1	
2	IC CARD COVER	2PP4128-1155P1	

6.3 Base unit

6.3.1 Zeichnung



6.3.2 Liste

NR.	BEZEICHNUNG	BESTELL-NR.	BEMERKUNG
1	BASE PLATE (ADHENSION)	2PP4083-7672G1	
2	CASSETTE GUIDE ASSY, L	3PP4083-7670G1	
3	CASSETTE GUIDE ASSY, R	3PP4083-7671G1	
4	SENSOR PLATE (PAPER SUPPLY)	4PP4083-7667P1	
5	INSULATOR	3PB4083-6144P1	
6	TQCB PCB	4YA4046-1662G1	
	(MAIN CONTROL PCB)		
7	POWER SUPPLY 120V	4YA4049-7100G1	
7	POWER SUPPLY 230V	4YA4049-7100G2	
8	TRANSFORMER 120V	4YB4049-7082P1	
8	TRANSFORMER 230V	4YB4049-7083P1	
9	FAN MOTOR	270A2167P0001	
10	CONTACT ASSY	3PA4083-6090G1	
12	CASSETTE SENSOR PLATE	3PP4083-6154P1	
13	PAPER CASSETTE	1PA4120-1162G1	
14	FLEXIBLE CORD (OP. PANEL)	238A1071P0001	
15	EARTH PLATE	4PP4083-6137P1	
16	FACE UP STACKER COVER ASSY	2PA4128-1143G1	
17	OPERATOR PANEL ASSY	4YA4083-7690G2	
18	SUMI CARD ASSY	4YX4046-1656G1	
19	LINK PULL BLOCK	4PP4122-1170P1	
20	CASSETTE LOCK LEVER	3PP4083-7653P1	
21	CASSETTE LOCK LEVER SPRING	4PP4083-7655P1	
22	SHEET SPRING	4PP4083-7666P1	
23	BEAM	3PP4083-7660P1	
24	SHEET LINK ASSY, L	4PP4083-7657G1	
25	SHEET LINK ASSY, R	4PP4083-7658G1	

6.4 2nd papertray

6.4.1 Zeichnung



6.4.2 Liste

NR.	BEZEICHNUNG	BESTELL-NR.	BEMERKUNG
1	HOPPING ROLLER SHAFT ASSY	3PA4122-1367G1	
2	ONE-WAY CLUTCH GEAR	4PB4122-1382P1	
3	STEPPING MOTOR	3PB4122-1399P1	
4	TQSB-2 PCB	4YA4046-1651G2	
5	CASSETTE ASSY	1PA4122-1362G4	
6	SEPARATION FRAME ASSY	4PP4120-1009G1	
7	UPPER PLATE	1PP4122-1401P1	
8	GEAR Z70	4PP4122-1207P1	
9	HOPPING FRAME ASSY	1PA4122-1366P1	
10	FEED EOLLER ASSY	3PA4122-1393G1	
11	REAR COVER	1PP4122-1323P1	
12	CASSETTE GUIDE ASSY (L)	1PA4122-1365G1	
13	BOTTOM PLATE	2PP4122-1389P1	
14	FRONT COVER ASSY	1PA4122-1369G1	
15	INNERGUIDE ASSY	3PA4122-1371G1	
16	GEAR Z24	4PP4122-1383P1	
17	BRACKET	4PP4122-1384G1	
18	GEAR Z87/60	4PP4122-1226P1	
19	CASSETTE GUIDE ASSY (R)	1YX4122-1364G2	
20	SHEET GUIDE ASSY	3PA4122-1370G1	
21	CABLE & CONNECTOR	3YS4111-3528P1	
22	SENSOR LEVER	3PP4122-1331P1	

6.5 Multi feeder (Universaleinzug)

6.5.1 Zeichnung



6.5.2 Liste

NR.	BEZEICHNUNG	BESTELL-NR.	BEMERKUNG
1	ROLLER A	3PB4083-5514P1	
2	ROLLER B	3PB4083-5524P1	
3	PLANET GEAR	4PP4083-5520P1	
4	LINK	3PP4083-5540P1	
5	SEPARATOR	4PP4083-5544G1	
6	STEPPING MOTOR	4PB4083-6075P1	
7	OLEV PCB	4YA4121-1014G11	
8	CONNECTOR CABLE	3YS4011-3141P1	
9	SEPARATOR ASSY (ENTHÄLT NR. 5)	3PA4083-5549G1	